


RAPTORTM | **USER MANUAL OF** **RAPTORTM Mini**

Thank you for purchasing the **Raptor mini** Before using this product for the first time please read this product manual carefully and keep it for future reference

Machine Overview



- | | | |
|---------------|--------------------------|------------------|
| 1. Handle | 2. "Power" Button | 3. Heating Light |
| 4. Heat Plate | 5. Insulated Safety Base | |

Details of Buttons

Safety Instructions



Power

Mode

Press once to turn the machine on and start preheating to 140°C(284°F);
Press twice to preheat to 160°C(320°F);
Press three times to preheat to 180°C(356°F);
Press four times to turn the machine off.

Instructions for Use

- Step 1** Power on the machine.
- Step 2** Press the "Power" button to turn on the machine and start preheating. The heating light is red during the process.
- Step 3** Once the heating light turns green, iron the fabric on the heat insulation pad (Not included) before use.
- Step 4** Place the materials on the fabrics.
- Step 5** Start ironing.

Precautions

1 Please iron the fabrics before transferring the images to them.

2 This machine will turn off automatically if there's no operation in 10 minutes.

3

This machine is a functional heating product. After use, please wait until it has completely cooled down before checking and storing it to avoid burns.

To reduce the risk of electric shock, this product has a polarized plug (one blade is wider than the other). This plug is intended to fit in a polarized outlet only one way. When the plug does not fit fully in the outlet, reverse the plug. When it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

Close supervision is required when this product is used near children.

HOUSEHOLD USE ONLY.

DO NOT IMMERSE IN WATER.

When the appliance provided with a power-supply cord that is less than 4 - 1/2 feet (1.4 m) long shall be provided with instructions that include the following information:

- a) A short power-supply cord (or short detachable power-supply cord) is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord;
- b) Extension cords (or longer detachable power-supply cords) are available and are not prohibited from being used when care is exercised in their use;
- c) When an extension cord is used:
 - 1) The marked electrical rating of the detachable power-supply cord or extension cord shall be no less than the marked electrical rating of the product;
 - 2) The longer cord shall be arranged so that it does not drape over the counter-top or tabletop where it is capable of being tripped over, snagged, or pulled on unintentionally, especially by children.

1. Do not use this product outdoors. It's only for household use;
2. This product has to work on a stable, flat, and heat-resistant surface. Pay attention to the safety of its surrounding environment while in use;
3. When using this product, please keep an eye on it to avoid accidents. Turn off the product and unplug the power cord while leaving;
4. Do not touch the heat plate and insulated safety base after powering on to prevent burns;
5. Do not let the power cord touch the heat plate during the operation;
6. Please unplug the power cord after use or before cleaning the product;
7. Please stop using the product immediately and contact customer service once the product is malfunctioned or damaged;
8. Do not immerse the product in any liquid;
9. Please keep the product in the insulated safety base while not in use;
10. Children under 14 years old MUST have adult supervision while using the machine.

CLEANING AND MAINTENANCE

Before performing cleaning and maintenance, ensure that the power supply has been turned off, unplug the power cord, and wait for the body to completely cool before performing cleaning and maintenance.

Do not put the appliance into water. Please use a soft dry cloth to dry the body without using special cleaning agents to clean it.

When the product is not in use, please clean it and place it in a clean and ventilated place, and store it out of the reach of children.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

Specifications

Product Name	Mini Heat Press	Model	RAPTOR™ Mini
Input Voltage	120V ~ 60 Hz ; 220 - 240V ~ 50 - 60 Hz	Power Consumption	250 W ; 450 - 550 W
Product Size	11.8 × 7.2 × 11.6 cm (4.6 × 2.8 × 4.6 in)	Package Size	22.5 × 8.0 × 12.5 cm (8.9 × 3.2 × 4.9 in)
Product Weight	0.5 kg(1.1 lb)	Package Weight	0.7 kg(1.6 lb)

Materials	Objects	Mode	Settings
PU Heat Transfer Vinyl	Cotton, Polyester, etc	Mode 1 (140°C) 284°F	Time: 15 s Pressure: Medium Cold/Warm Peel
PVC Heat Transfer Vinyl	Cotton, Polyester, etc	Mode 1 (140°C) 284°F	Time: 15 s Pressure: Medium Cold/Warm Peel
Glitter Heat Transfer Vinyl	Cotton, Polyester, etc	Mode 2 (160°C) 320°F	Time: 15 s Pressure: Medium Cold/Warm Peel
Sublimation Paper	Polyester, Cotton≤30 %, etc	Mode 3 (180°C) 356°F	Time: 45 s Pressure: Medium Hot Peel
Heat Transfer Paper (Dark Fabric)	100 % Cotton	Mode 2 (160°C) 320°F	Time: 15 s Pressure: Heavy
Heat Transfer Paper (Light Fabric)	100 % Cotton	Mode 2 (160°C) 320°F	Time: 15 s Pressure: Medium