
dE: DR Input Signal Error diagnosis and solution

Description: If a DR input error signal is received, the LED displays the failure code.

Recommended parts to prepare:

- DR board

Troubleshooting and repair:

