
CL (Clean filter)

Description: It is not error, It reminds you to clean filter when the 88 displays this code(power on display for 15 seconds).

For Xtreme and INFINI series,when Active Clean feature is turned on(For Inverter split type) and when unit is self-cleaning(For Fixed-speed type), the 88 displays this code.