
Defrost

Description: It is not error, when the AC is defrosting, the LED displays this code.

For some outdoor units, in defrosting mode, "dF" & running frequency are shown in a alternate display(each appears for 0.5s).