



Roku Installation Guide


Follow these simple steps to set up your DirectConnect service

Initial Setup

Plug your Roku into the TV's HDMI port, connect power, select the HDMI input, pair the remote, connect to Wi-Fi, and follow the on-screen prompts to link your Roku account. Note: Setup screens may vary slightly by Roku model.

Installation Steps

- 1 Step 1: Home Page (Preview)**
From the Roku Home screen, press the West (left) arrow on your remote for options to appear. Then press the South (down) arrow and select Search.
- 2 Step 2: Search & Add App**
Type "Ib Pro Player," select it from results, press OK to Add App, and wait for download.
- 3 Step 3: Confirm App Added**
Press OK after "App added" confirmation. Note: 7-day free trial, then \$10/device.
- 4 Step 4: Go to Settings**
In the app, navigate right to Settings and press OK.
- 5 Step 5: Select Change Playlist**
Press OK on Change Playlist. Steps below require your cellphone.
- 6 Step 6: Phone Setup**
Scan QR code or visit <https://iboproapp.com>. Go to Manage Playlists.
- 7 Step 7: Enter Device Info & Add Playlist**
Enter Mac Address & Device Key from TV. Select Log In, then Add XC Playlist.
- 8 Step 8: Enter Playlist Details**
Name: DirectConnect | Host: <http://hostengine.live:25461> | Enter credentials. Submit.
- 9 Step 9: Reopen App & Select Live**
Close and reopen the app, select Live. You are ready to watch DirectConnect!



Troubleshooting Tips

- Buffering? Check your internet speed or try a wired connection.
- App crashing? Clear cache and restart the app.
- No channels loading? Verify your credentials and server URL.
- Need help? Contact support at support@directconnect.tv

www.directconnect.tv | support@directconnect.tv